

Mint Chocolate Chip Fudge

1. Prior to making, freeze the chocolate chunks so that they don't melt.
 2. Add cream powder to hot water and stir with a wire whip until there are no lumps.
 3. Add dry ingredients.
 4. No scraps go into this fudge.
 5. Turn stove on high and stir constantly until ingredients all liquefy, then stir as needed.
 6. Keep mixture low in the kettle while cooking.
 7. Turn stove off so that temperature goes to exactly 237degrees (+ or – adjustment for thermometer calibration, temperature, humidity, and barometric pressure).
 8. If you overshoot the temperature add ¼ qt. water and cook up ½ degree **above the original finish temperature.**
 9. Add butter and stir until it is melted.
 10. Pour into bars on marble table.
 11. Let cool to about 100 degrees.
 12. Add flavoring, coloring and start paddling to mix in.
 13. Begin paddling process.
 14. On last few loafing passes, add chocolate chunks and spread evenly through the loaf.
 15. Finish loafing process.
- *For total recook batches add 1 qt. water and cook up ½ degree plus extra ½ degree if fudge was too soft.*