

## Rocky Road Fudge

1. Prior to making, freeze the mini-marshmallows so that they do not melt.
  2. Add cream powder to hot water and stir with a wire whip until there are no lumps.
  3. Add dry ingredients.
  4. Add no more than two pounds of Rocky Road, Chocolate, and/or Chocolate Pecan fudge scraps.
  5. Turn stove on high and stir constantly until ingredients all liquefy, then stir as needed.
  6. Keep mixture low in the kettle while cooking.
  7. Turn stove off so that temperature goes to exactly 236 degrees (+ or – adjustment for thermometer calibration, temperature, humidity, and barometric pressure).
  8. Add butter and stir until it is melted.
  9. If you overshoot the temperature add  $\frac{1}{4}$  quart water and cook up  $\frac{1}{2}$  degree **above the original finish temperature.**
  10. Pour into bars on marble table.
  11. Let cool to about 100 degrees.
  12. Add flavoring and start paddling to mix in.
  13. Add pecan pieces and continue paddling.
  14. During last few loafing passes, add frozen miniature marshmallows.
  15. Finish loafing process.
- \*For total recook batches add 1 qt. water and cook up  $\frac{1}{2}$  degree plus extra  $\frac{1}{2}$  degree if fudge was too soft.*